




PREVENTIVE MAINTENANCE

Key no	Qty	Designation	Ref.
	1	Lot d'ent. boîte à clapets incl./ Valve assembly maintenance kit includes	3050879502
3	2	Joint / Seal	
5	1	Bille / Ball	
6	1	Siège de bille / Seat	
1		Lot d'entretien incluant / Maintenance service kit includes	3071240048
	2	Lot d'entretien boîte à clapets / Valve assy maintenance kit	
8	1	Membrane / Diaphragm	
14	1	Ressort / Spring	

CORRECTIVE MAINTENANCE

Key no	Qty	Designation	Ref.
1 + 2	1	Ecrou + Raccord / Nut + Connection	3050977007
8	1	Ressort / Spring	0800123026
10+12	1	Corps de doseur avec visserie / Liquid end body with screws	3071240043
14	1	Membrane / Diaphragm	3050976110
S	1	Boîte à clapets (asp.) / Valve assembly (suction)	3050870019
T	1	Boîte à clapets (ref.) / Valve assembly (Discharge)	3050870069
U	1	Doseur complet / Liquid end assembly	541H