




PREVENTIVE MAINTENANCE

Key no	Qty	Designation	Ref.
	1	Lot d'ent. boîte à clapets incl./ <i>Valve assembly maintenance kit includes</i>	3050879512
3	3	Joint / Seal	
5	1	Bille / Ball	
6	1	Siège de bille / Seat	
	1	Lot d'entretien incluant / <i>Maintenance service kit includes</i>	3071240059
	2	Lot d'entretien boîte à clapets / <i>Valve assy maintenance kit</i>	
8	1	Membrane / <i>Diaphragm</i>	
14	1	Ressort / <i>Spring</i>	

CORRECTIVE MAINTENANCE

Key no	Qty	Designation	Ref.
1 + 2	1	Ecrou + Raccord / Nut + Connection	3050977107
8	1	Ressort / Spring	0800083026
10+12	1	Corps de doseur avec visserie / Liquid end body with screws	3071240054
14	1	Membrane / Diaphragm	3050976090
S	1	Boite à clapets (asp.) / Valve assembly (suction)	3050629019
T	1	Boite à clapets (ref.) / Valve assembly (Discharge)	3050629159
U	1	Doseur complet / Liquid end assembly	561H