




PREVENTIVE MAINTENANCE

Key no	Qty	Designation	Ref.
1		Lot d'ent. boîte à clapets incl./ Valve assembly maintenance kit includes	3050879512
3	3	Joint / Seal	
5	1	Bille / Ball	
6	1	Siège de bille / Seat	
1		Lot d'entretien incluant / Maintenance service kit includes	3071240070
	2	Lot d'entretien boîte à clapets / Valve assy maintenance kit	
8	1	Ressort / Spring	
14	1	Membrane / Diaphragm	

CORRECTIVE MAINTENANCE

Key no	Qty	Designation	Ref.
1 + 2	1	Ecrou + Raccord / Nut + Connection	3050977107
8	1	Ressort / Spring	0800083026
10+12	1	Corps de doseur avec visserie / Liquid end body with screws	3071240067
14	1	Membrane / Diaphragm	3051062010
S	1	Boîte à clapets (asp.) / Valve assembly (suction)	3050629019
T	1	Boîte à clapets (ref.) / Valve assembly (Discharge)	3050629159
U	1	Doseur complet / Liquid end assembly	581H