


POMPE SERIE G SERIES G PUMP

M50Q

ENSEMBLE DOSEUR LIQUID END ASSEMBLY



MAINTENANCE PREVENTIVE PREVENTIVE MAINTENANCE

Rep/Key	Qté/ Qty	Désignation/ Description	M50Q
	1	Lot d'ent. boîte à clapets incl. / Valve assembly maintenance kit includes	3050879502
3	2	Joint / Seal	
5	1	Bille / Ball	
6	1	Siège / Seat	
	1	Lot d'entretien incluant / Maintenance service kit includes	3071240175
	2	Lot d'entretien boîte à clapets / Valve assy maintenance kit	
14	1	Membrane / Diaphragm	

MAINTENANCE CORRECTIVE CORRECTIVE MAINTENANCE

Rep/Key	Qté/ Qty	Désignation/ Description	M50Q
1+2	1	Ecrou + Raccord / Nut + Connection	3050977007
10+12	1	Corps de doseur avec visserie / Liquid end body with screws	3071240176
14	1	Membrane / Diaphragm	3050976090
A*	1	Clapet de pied / foot valve (option)	77075
C*	1	Canne d'injection / Injection pipe (option)	77073
S	2	Boîte à clapets / Valve assembly	3050870019
U	1	Doseur complet / Liquid end assembly	M50Q

* non représenté sur la figure / not shown on the drawing